



1809

Figure 1. Edit Kit Part No. 4010292-AA or -AB

8. Mount support block in hole previously used for template, using 1-inch screw, plain washer, and lock washer.
9. Mount marking block on transport front overlay, using two 1/4-inch-long screws and plain washer. Do not tighten screws.
10. Set transport front overlay assembly aside and proceed with installation.
11. Lower ATR-100 front panel.
12. Examine left forward underneath side of transport mounting for two screws holding filler panel in place (see Figure 2). If two screws are present proceed to step 14. If two screws are not present proceed to step 13.
13. Pop out filler panel and proceed to step 25.