



Figure 3. Rear Overlay Panel, Six Mounting Screws

21. Disconnect control panel connector P11 from electronics assembly double-sided connector J11.
22. From the top of the transport, remove three 6-32 cap screws (Figure 5) that secure the electronics assembly to the transport.
23. From the bottom of the transport, slide electronics assembly chassis toward the supply reel and lift electronics assembly from the transport.
24. Remove left-hand filler panel by removing four flat-head screws accessible from the bottom of the transport casting.
25. Set tray in space created by removal of filler panel.
26. Reinstall electronics assembly in the reverse order of removal, being careful not to damage any cables (especially cable/connector P10).