



NOTES:

1. PART NO. IS 4010292-XX
2. MARK PART NO. PER BDI-1.
3. TEMPLATE TO BE PLACED ON FAR SIDE OF OVERLAY USING ITEM #19 AND #20 FOR DRILLING HOLES FOR ITEM #1.
4. ON OVERLAY PART #4110296-01 DRILL 2 HOLES .156 DIA. THRU, CBORE .312 DIA. X .16 DEEP, FAR SIDE. ON OVERLAY PART #4110302-02 DRILL 2 HOLES .156 DIA THRU.
5. BOND ITEM 3 OR 4 TO COVER AS SHOWN.
6. ALIGN ITEM 1, MARKING BLOCK "V", 1.50 IN. FROM THE PLAY HEAD GAP.

Assembly No. 4010292. Edit Kit